










## Dell 27 Plus QHD USB-C Monitor

S2725DC


### Quick Start Guide












1





2




























Dell Display and Peripheral Manager  
[Dell.com/support/ddpm](https://Dell.com/support/ddpm)



[Dell.com/support/S2725DC](https://Dell.com/support/S2725DC)